



Scan for full manual

## PNL-BLK-10MT-5-SET Quick Start Guide

This guide helps you install and use your PNL-BLK-10MT-5-SET for the first time.

Go to [www.kramerav.com/downloads/PNL-BLK-10MT-5-SET](http://www.kramerav.com/downloads/PNL-BLK-10MT-5-SET) to download the latest user manual and check if firmware upgrades are available.


### Step 1: Check what's in the box

✓ PNL-BLK-10MT-5-SET Blank Panel Set (includes 5 blank panels)

✓ 1 Quick start guide

### Step 2: Get to know your PNL-BLK-10MT-5-SET

The PNL-BLK-10MT-5-SET includes 5 blank panels that can be used to cover unused openings in the RK-10MT rack adapter.



#	Feature	Function
1	Knob	Turn to attach a panel to the rack.
2	Blank Panel	Blank panel to cover open slot.


### Step 3: Mount PNL-BLK-10MT-5-SET



- Ensure that the environment (e.g., maximum ambient temperature & air flow) is compatible for the device.
- Avoid uneven mechanical loading.

To mount a device onto the rack:

1. Place the blank over the rack opening.
2. Turn the knobs on both sides clockwise to secure the blank panel to the rack.



## Technical Specifications

Environmental Conditions	Operating Temperature	0° to +40°C (32° to 104°F)
	Storage Temperature	-40° to +70°C (-40° to 158°F)
	Humidity	10% to 90%, RHL non-condensing
Regulatory Compliance	Safety	CE
	Environmental	RoHs, WEEE
Enclosure	Type	SGCC
General	Net Dimensions (W, D, H)	25.6cm x 4cm x 2.1cm (10.1"x 1.6" x 0.83"), per blank panel
	Shipping Dimensions (W, D, H)	31.2cm x 17.9cm x 7.6cm (12.3" x 7" x 3")
	Net Weight	0.54kg (1.2lbs) approx.
	Shipping Weight	0.78kg (1.7lbs) approx.